



## RS-422 Line Booster

### Model 422LB

The RS-422 Line Booster is used to amplify and square up RS-422 balanced signals. The RS-422 Standard recommends that the cable length be no longer than 4000 feet. By inserting Line Boosters at 4000 foot intervals, the cable can be extended as long as you wish.



© 1993 B&B Electronics - June 1993

*This product designed and manufactured in USA of domestic and imported parts by*

Phone: (815) 433-5100  
Office Fax: (815) 433-5105  
Tech Fax: (815) 433-5104  
Sales Fax: (815) 433-5109

**B & B electronics**  
MANUFACTURING COMPANY  
707 Dayton Road -- P.O. Box 1040 -- Ottawa, IL 61350 USA

Home Page: [www.bb-elec.com](http://www.bb-elec.com)  
E-mail: [orders@bb-elec.com](mailto:orders@bb-elec.com)  
[support@bb-elec.com](mailto:support@bb-elec.com)  
[catrqst@bb-elec.com](mailto:catrqst@bb-elec.com)